


**2 YEAR WARRANTY** (RESTRICTIONS APPLY)

Imada, Inc. warrants its products to the original purchaser to be free from defects in workmanship and material under normal use and proper maintenance for two years (one year for adapters, attachments and cables) from original purchase. This warranty shall not be effective if the product has been subject to overload, shock load, misuse, negligence, accident or repairs attempted by others than Imada, Inc.

During the warranty period, we will, at our option, either repair or replace defective products. Please call our customer service department for a return authorization number and return the defective product to us with freight prepaid.

The foregoing warranty constitutes the **SOLE AND EXCLUSIVE WARRANTY**, and we hereby disclaim all other warranties, express, statutory or implied, applicable to the products and/or software, including but not limited to all implied warranties of merchantability, fitness, non-infringement, results, accuracy, security and freedom from computer virus. In no event shall Imada, Inc. and/or its affiliated companies be liable for any incidental, consequential or punitive damages in connection with the use of its products and/or software.

# Digital Torque Gauge



**Model HTG2**

# INSTRUCTION MANUAL

*Specifications subject to change without notice.*

## INTRODUCTION


Model HTG2 is a highly sophisticated, torque tester which offers programmable high/low setpoints for go/no go testing. Store up to 1,000 values into memory, which can be transmitted using Digimatic or RS-232 formats. Use the Real Time mode to display torque transients, or the Peak mode to capture the peak torque achieved during a test. Select measuring units between lbf-in or ozf, kgf-cm and N-cm.

## PRECAUTIONS

HTG2 Torque Tester is a sensitive instrument. The torque sensor can be damaged regardless of whether the unit is ON or OFF. *Follow these precautions to keep your HTG2 from being damaged.*

1. **WARNING!!** Do not exceed unit's capacity regardless if power is on or off.
2. Only use the Imada AC adapter/charger, other brands may cause serious damage.
3. Accuracy may be affected if unit is exposed to high humidity, dust or extreme shock.
4. Do not disassemble unit. Disassembly voids warranty.
5. Recommended re-calibration cycle is one (1) year.


## DIMENSIONS



Model	Capacity (Resolution)		
	lbf-in	kgf-cm	N-cm
HTG2-4	70.00 (0.01 ozf-in)	5.000 (0.001 kgf-cm)	50.00 (0.01 N-cm)
HTG2-15	15.00 (0.01 lbf-in)	20.00 (0.01 kgf-cm)	200.0 (0.1 N-cm)
HTG2-40	40.00 (0.01 lbf-in)	50.00 (0.01 kgf-cm)	500.0 (0.1 N-cm)
HTG2-85	85.0 (0.1 lbf-in)	100.0 (0.1 kgf-cm)	1000 (1 N-cm)

## Imada HTG2 Series Specifications

<b>Accuracy</b>	± 0.5% F.S. ± 1 LSD
<b>Selectable Units</b>	ozf-in or lbf-in, kgf-cm, and N-cm
<b>Overload Capacity</b>	200% of F.S. Overload indicator flashes beyond 110% of F.S.
<b>Power</b>	Rechargeable Ni-MH battery pack or Imada AD120/230 adapter
<b>Battery Indicator</b>	Icon flashes when battery is low
<b>Battery Life</b>	approx. 8 hours (recharge time approx. 10 hours)
<b>Memory</b>	Non-volatile, recall up to 1000 data
<b>Setpoints</b>	Programmable high/low setpoints with color-coded LED indicators and output signal
<b>Outputs</b>	RS-232C, Digimatic and ± 2 VDC analog output
<b>Auto Power Off</b>	5, 10, 30, 60 minutes or OFF (selectable)
<b>Operating Temp.</b>	32° to 100°F (0° to 40°C)




- ① **Programmable Setpoint LED's**  
When high-low setpoints are set, LED indicates below (-NG), within (OK), or above set point value (+NG).
- ② **CW icon**  
Indicates CW measurement.
- ③ **CCW icon**  
Indicates CCW measurement.
- ④ **Reverse +/- values**
- ⑤ **Auto Zero Reset icon**  
Programmable auto zero reset duration
- ⑥ **Auto Memory - Peak Reset icon**
- ⑦ **Battery icon**  
Flashes when Ni-MH cells need charging.
- ⑧ **PEAK icon**  
Displays continuously when peak function is active.
- ⑨ **HOLD icon**  
Displays when external hold signal is active or SEND button is pressed.
- ⑩ **Alarm Icon**
- ⑪ **Auto Power Off icon**
- ⑫ **Units icon**  
Displays selected measuring units. (ozf-in, lbf-in, kgf-cm, N-cm)
- ⑬ **Overload Indicator**  
Flashes at 110% of rated capacity.

## PREPARATION

Connect the coiled cable to both the measuring chuck and display unit by rotating the round cable connector to find the matching groove, then pushing in until positive connection is made.

To disconnect, first slide the ribbed cover of the connector back, then pull out the connector (DO NOT ROTATE THE CONNECTOR).



## OPERATION

### Selecting Units

Press **ON/OFF** to turn on the gauge. The LCD display briefly shows the capacity of the gauge and then zero with a measuring unit (factory setup is lbf-in or ozf-in). If you want to change to other units:

1. Turn off the gauge.
2. Press **ON/OFF** again while holding **ZERO** to enter Power-Off programming mode (CF9 flashes with solid nn0).
3. Press **SEND** to display U-03 with a unit, then press **PEAK** or **ZERO** to cycle desired units (ozf-in, lbf-in, kgf-cm and N-cm), and press **SEND** to select (CF9 flashes with solid End).
4. Press **ON/OFF** to exit 1st. programming mode.

Once units are selected, the gauge retains them as a default.

## Power-Off programming (clear data from memory)

Turn off the gauge. Press **ON/OFF** again while holding **SEND** to enter memory mode.

### Memory clear

Memory location and value cycle. Press PEAK or ZERO to increase or decrease memory location (and corresponding value).

**Single Memory Clear** A memory location with a dot at both ends is the last stored data and the only one that can be erased. Press SEND to erase, ErASed is displayed. If you attempt to erase other locations Error is displayed. Press ON/OFF to exit.

**All Memory Clear** While a memory value or location is displayed, press SEND for 3 seconds, all data is erased and ErASed is displayed, then -----. Press ON/OFF to exit.

## Power-Off programming

Turn off the gauge. Press **ON/OFF** again while holding **ZERO** to enter Power-Off programming (CF9 flashes with solid m0). Press **PEAK** or **ZERO** to cycle CF9m0, CF9m1, CF9m2, CF9m3(USB models only) and CF9End. Press **SEND** to select a function.

### CF9 m0 Units selection

Press PEAK or ZERO to cycle; 'U-01': kgf-cm, 'U-02': N-cm, 'U-03': lbf-in or ozf-in  
Press SEND to select, CF9End displays. Press SEND to exit.

### CF9 m1 Torque dampening

Factory set='Fd6'

Press PEAK or ZERO to cycle: 'Fd0, Fd 1, Fd2, Fd3, Fd4, Fd5 or Fd6'. Torque dampening averages rapid torque changes over time. Larger numbers allow more dampening. Press SEND to select, CF9End displays, press SEND to exit (Torque dampening rate displays each time the gauge is turned on).

### CF9 m2 +/- indicator

Default='SC-OFF'

Press PEAK or ZERO to cycle. 'SC-OFF': CW (+) and CCW (-) or 'SC-On': CW (-) and CCW (+). Press SEND to select, CF9End displays, press SEND to exit.

**Note:** All power-on and power-off programming functions except for unit selection and display orientation can be reset to factory defaults by the following procedure.

Turn on the gauge Press PEAK and ZERO for 3 seconds to display flashing CF9 with solid F0. Press ZERO and PEAK for 5 seconds until flashing CF9 disappears and becomes only solid F0. Then release both PEAK and ZERO. Gauge goes back to measuring mode with factory default settings.

## Power-On programming

Turn on the gauge. Press **PEAK** and **ZERO** for 3 seconds to enter Power-On programming (CF9 flashes with solid F0). Press **PEAK** or **ZERO** to cycle CF9 F0, CF9 F1, CF9 F2, CF9 F3, CF9 F4, CF9 F5, CF9 F6 and CF9 End. Press **SEND** to select a function.


<b>CF9 F0</b>	<b>Memory recall</b>	
Press SEND, memory location and value cycle. Press PEAK or ZERO to increase or decrease memory number (and corresponding value). Press SEND to exit.		
<b>CF9 F1</b>	<b>High &amp; low setpoints</b>	Default='0' both Hi and Lo
Press SEND, -HI- displays, then the high set value (i.e. H 10.0). Press PEAK to increase and ZERO to decrease, press SEND to select. -LO- displays then the low set value (i.e. L 5.0). Press PEAK to increase and ZERO to decrease, press SEND to select, CF9 End displays. Press SEND again to exit.		
<b>CF9 F2</b>	<b>Peak mode</b>	Default='Or'
Press SEND, 'Or' or 'And' displays. Press PEAK or ZERO to cycle. Press SEND to select. 'Or Peak' records the Peak in either CW or CCW during test. 'And Peak' records both the CW peak and CCW peak during a test.		
	<b>Zero reset memory store</b>	Default='AA-OFF'
Auto memory displays after Peak mode is selected. 'AA-On' enables automatic memory storage and reset to zero. 'AA-OFF' turns off auto function. Press PEAK or ZERO to change. Press SEND to select, CF9End displays, press SEND again to exit.		
<b>CF9 F3</b>	<b>Auto zero reset</b>	Default='Ac-OFF'
Press SEND, 'Ac-On' or 'Ac-OFF' displays. Press PEAK or ZERO to cycle. If 'Ac-On' is selected, auto zero reset duration can be programmed. Press PEAK to increase or ZERO to decrease. Press SEND to select, CF9End displays, press SEND again to exit (i.e. 'SEC 3.0' is displayed for auto zero reset duration of 3 seconds).		
<b>CF9 F4</b>	<b>Audible beep</b>	Default='Sd-On'
Press SEND, 'Sd-On' for alarm on, or 'SD-OFF' for off displays. Press PEAK or ZERO to cycle. Press SEND to select. CF9End displays, press SEND again to exit (alarm sounds for values over HI or under LO setpoints).		
	<b>Setpoint alarm</b>	Default=''
Setpoint alarm displays after audible beep is selected. 'AL-On' for setpoint alarm on or 'AL-OFF' for off. Press PEAK or ZERO to cycle. Press SEND to select, CF9End displays, press SEND again to exit.		
<b>CF9 F5</b>	<b>Reverse display</b>	
Press SEND, '-12345' for standard or 'ꠤꠥꠇꠤ-' for reverse displays. Press PEAK or ZERO to cycle. Press SEND to select. Flashing CF9 with solid End displays. Press SEND again to exit. (for vertical mounting).		
<b>CF9 F6</b>	<b>Auto power off duration</b>	Default='AO-10'
Press SEND, 'AO-10' displays. Press PEAK or ZERO to cycle 'AO-5' for 5 min auto power off duration, 'AO-10' for 10 min, 'AO-30' for 30 min, 'AO-60' for 60 min and 'AO-OFF' to by-pass auto power off. Press SEND to select, CF9End displays, press SEND again to exit.		

## Reversing the Display

The factory default is standard display.

To reverse the display:

1. Turn on the gauge
2. Press **PEAK** and **ZERO** for 3 seconds to enter Power-On programming mode (CF9 flashes with solid F0).
3. Press **PEAK** 5 times to display flashing CF9 with solid F5, then press **SEND** to display -12345. Press **PEAK** or **ZERO**, to cycle between standard and reverse ꠤꠥꠇꠤ- .
4. Press **SEND** to select, the display flashes CF9 with solid End.
5. Press **SEND** again to exit Power-On programming mode.



Once desired display is selected, the gauge retains it as a default.

## Programming Setpoints (optional)


Program High and Low setpoints for easy GO/NO GO testing.

1. Turn on the gauge
2. Press **PEAK** and **ZERO** for 3 seconds to enter Power-On programming mode (CF9 flashes with solid F0).
3. Press **PEAK** to display flashing CF9 with solid F1, then press **SEND** to display -HI- and then the high set value (i.e. H 10.0).
4. Press **PEAK** to increase and **ZERO** to decrease the High set value, then press **SEND** to display -LO- and then low set value (i.e. L 5.0). Press **PEAK** to increase and **ZERO** to decrease the Low set value and press **SEND** to display flashing CF9 with solid End.
5. Press **SEND** again to exit Power-On programming mode.



## Peak or Real time Measuring Mode


Press **ON/OFF** to turn on and the gauge automatically enters real time measuring mode. For peak measurement press **PEAK**. The “Peak icon” appears on the display. Peak readings will not change until a higher value is measured. Press **PEAK** again to return to real time mode.



“Or PEAK“ is the factory default which measures peak CW torque or peak CCW torque. “And PEAK“ measures both peak CW torque and peak CCW torque during a test. Refer to the F2 function of the Power-On programming table for the “And PEAK” function.

## Tare

Clamp test sample firmly by tightening the key. If necessary, press **ZERO** to tare before the test. Pressing **ZERO** also clears the peak reading.



If High and Low setpoints have been programmed (see page 5), for example, 5 lbf-in is set as Low and 10 lbf-in as High, the ORANGE LED light for measurements less than 5 lbf-in (Low setpoint). GREEN lights between 5–10 lbf-in and RED lights over 10 lbf-in (High setpoint). Setpoint output is available through the Communications port (see page 7).

After measuring, press the **SEND** button to transmit data to:

RS-232 models: RS-232C or Digimatic devices

## Storing Data into Memory

During measurement whether Peak or Real Time, press **SEND** to store and display up to 1000 torque values into memory. (If no data is stored - - - - - is displayed then flashing CF9 with solid End).

## RECHARGING NI-MH BATTERY


1. To maximize the life of the battery, power is automatically shut off after 10 minutes of non-use or user-defined interval. Automatic shut off is bypassed during USB output or when used with the AC adapter/charger.
2. Battery icon will flash when the gauge needs to be recharged.
3. Push **ON/OFF** to turn off power. Only use the IMADA AC adapter/charger provided, AD120 for 115VAC, AD230 for 230VAC. Plug into the correct AC output. It takes 10 hours to charge fully.
4. When the gauge is turned off, make sure the AC adapter/charger is disconnected to avoid overcharging.




## OPTIONAL CABLES



10' Analog cable  
CB-104



10' RS-232C cable, 9 pin female  
CB-204



10' Digimatic Cable  
CB-304

## 2. Mitutoyo Digimatic Signal


Connect the CB-304 cable to the communications port and the device receiving the data. Set up parameters as instructed from the Mitutoyo processor manual.

## 3. $\pm 2$ VDC Analog Signal

Connect the CB-104 analog cable to the communications port and the device receiving the data.

## 4. External Switch Display Freeze

By connecting #10 and #12 of the communications port, the gauge instantaneously captures the critical reading and holds the display from remote locations (use contact closure and **DO NOT** apply voltage across #10 and #12).



- (1) Pay extra attention to avoid overload as display value will not change during display hold.
- (2) Use contact closure only and **DO NOT** apply voltage across #10 and #12 port pins.

## 5. External Switch Display Clear

By connecting #8 and #12 of the communications port, display can be cleared from remote locations (use contact closure and **DO NOT** apply voltage across).



Use contact closure only and **DO NOT** apply voltage across #8 and #12 port pins.

## Recalling Data from Memory

1. Turn on the gauge.
2. Press **PEAK** and **ZERO** for 3 seconds to enter Power-On programming (CF9 flashes with solid F0). Press **SEND** and the display cycles memory location and value. Press **PEAK** to increase location and **ZERO** to decrease. Press **SEND** to exit.

## Clearing Data from Memory

1. Turn off the gauge.
2. Press **ON/OFF** again while holding **SEND** to enter memory mode.

### Single Memory Clear

A memory location with a dot at both ends is the last stored value and the only one that can be erased. Press **SEND** to erase and ErASEd is displayed. If you erase any other location Error is displayed.

### All Memory Clear

While a memory location or value is displayed, press **SEND** for 3 seconds, all data is erased, ErASEd is displayed, then - - - - and flashing CF9 with solid End. Press **ON/OFF** to exit. (See page 14-15).

## Downloading Data from Memory

Choose between the following download methods.


### Digimatic Data Download from Memory

1. Connect the gauge and device receiving data with CB-304 cable.
2. Turn on the gauge. Press **PEAK** and **ZERO** for 3 seconds to enter Power-On programming (CF9 flashes with solid F0).
3. Press **SEND** to transmit all data.
4. Press **SEND** again to exit.

### RS-232C Data Download from Memory

Connect the gauge and device receiving data with a CB-204 cable. Use the I[CR] ASCII command to transmit data (uppercase ASCII character format).

## COMMUNICATIONS PORT



### COMMUNICATIONS PORT PIN DEFINITIONS

PIN#	DEFINITION	
1	RS-232C Signal Output	RS-232C Output
2	RS-232C Receive Signal	
3	RS-232C Ground	
4	Analog Output $\pm 2$ VDC	Analog Output
5	Analog Ground	
6		External Inputs
7		
8	External Switch Display Clear	
9	External Switch for Peak/Real Time Modes	
10	External Switch Display Freeze	
11		
12	Ground	
13	Ground	
14		
15		
16	Digimatic Data Request	Digimatic Output
17	Digimatic Data Ready	
18	Digimatic Data Clock	
19	Digimatic Data Signal Out	
20	Digimatic Data Ground	
21	+NG Output	<p>High/Low Setpoint and Overload Output (open collector= 30V, 10mA max)</p>
22	OK Output	
23	-NG Output	
24	Overload Output	
25	Common	
26	Common	

## 1. RS-232C bi-directional interface functions

All functions can be duplicated remotely by using the RS-232C interface. Commands must be sent in uppercase ASCII character format followed by a carriage return [CR].

RS-232C Signal: 8 data, 1 stop, no parity. Baud Rate: 19200 bps

### RS-232C INTERFACE FUNCTIONS (Upper case ASCII format)

COMMAND	FUNCTION	RESPONSE*
<b>T[CR]</b>	Select real time mode	R[CR]
<b>P[CR]</b>	Select peak mode If OR peak is programmed <b>P[CR]</b> = peak If AND peak is programmed <b>P[CR]</b> (1st time)= +peak <b>P[CR]</b> (2nd time)= - peak	R[CR]
<b>Z[CR]</b>	Tare Display	R[CR]
<b>D[CR]</b>	Transmit display data	[direction][value][units][mode] [go/nogo/overload][CR] [direction] +=CW - =CCW [value] 4 digits w/decimal [units] K, N, or O [mode] T=real time value P=peak value H=Hold value M=Memory value [go/nogo] H=+NG O=OK L=-NG E=Overload
<b>V[CR]</b>	Transmit Peak data	P+[value][units][CR] P-[value][units][CR]
<b>g[CR]</b>	Continuous data output (10 data/sec)	
<b>Y[CR]</b>	Stop continuous data output	
<b>K[CR]</b>	Select "kgf-cm" units	R[CR]
<b>N[CR]</b>	Select "N-cm" units	R[CR]
<b>O[CR]</b>	Select "lbf-in" units	R[CR]
<b>B[CR]</b>	Delete last data stored in memory	R[CR]
<b>M[CR]</b>	Store data	R[CR]
<b>I[CR]</b>	Recall memory data	Data format is the same as <b>D</b> command response. It will output END[CR] at the end of data
<b>C[CR]</b>	Clear memory	R[CR]
<b>EXXXYYYY[CR]</b>	Set high/low setpoints(4 digit) XXXX=High, YYYY=Low	R[CR]
<b>E[CR]</b>	Read high/low	EXXXYYYY[CR] setpoint values (4 digit) XXXX=High, YYYY=Low

\*Note: E[CR] response if the command is not accepted.