

# PC Connection Guide

The diagram below depicts the cables and adapter needed to output force and travel data to a PC.

